

Detachable Motion Sensor Security Light

Item ref: 154.845UK & 154.846UK

User Manual

Thank you for purchasing this Lyyt Detachable Motion Sensor Security Light.

Before starting, please ensure that you have read this instruction leaflet carefully. If you are unsure about any of the installation details, please consult a professional.

Installation

Detach the spherical torch from the mount by pulling firmly.
Twist the torch to unlock the battery compartment.
Install 3 x AAA Batteries making sure to match the polarities correctly.
Twist the torch to lock the two halves together again.
Snap the torch back into the mount and align to the required position.

Operation

The switch on the torch has three positions:

- ON:** Permanently on
- OFF:** Permanently off
- AUTO:** The unit will operate when motion is detected within range and will remain on for 25-30 seconds before switching off.

Specification

Material	ABS
Detection Range	Max 3m
Detection Angle	120°
Batteries	3 x AAA (Not Supplied)
IP Rating	IP20 for indoor or sheltered outdoor use



This product is classed as Electrical or Electronic equipment and should not be disposed with other household or commercial waste at the end of its useful life. The goods must be disposed of according to your local council guidelines.

Errors and omissions excepted.

Copyright© 2024 AVSL Group Ltd, Unit 2 Bridgewater Park,
Taylor Road, Trafford Park, Manchester. M41 7JQ.

AVSL (Europe) Ltd, Unit 3D North Point House,
North Point Bus. Park, New Mallow Road, Cork, Ireland